

Understanding Fire Pumps and Fire Mains


An owner's guide to seawater supply, pressure, hydrants and firefighting reach

A hose is useful only when water reaches it at sufficient pressure from a safe source.

Readiness depends on suction, power, access and a crew able to deploy the system quickly.

Absolute Marine

Commercial thinking for private cruising.



SUPPLY | PRESSURISE | APPLY

GUIDE OVERVIEW

What fire pumps and fire mains are designed to do

A fire-main system draws water from the sea, pressurises fixed pipework and delivers a controllable stream through hydrants, hoses and nozzles for firefighting, exposure protection and boundary cooling.

SCOPE

This guide covers common fixed fire-main arrangements on larger cruising yachts, including dedicated and shared pumps, emergency alternatives, hydrants, hoses and nozzles. Actual capacities and statutory requirements vary with vessel size, flag, coding and construction.

By the end of this guide, you should be able to:

- Trace the route from sea suction to pump, main, hydrant, hose and nozzle.
- Understand the difference between pump nameplate capacity and useful pressure at the point of attack.
- Recognise blocked suctions, loss of prime, valve errors, pipe leakage and inaccessible firefighting equipment.
- Understand why an emergency pump should not share every vulnerability with the normal pump.
- Ask better questions during purchase, survey, refit, drills and offshore preparation.

CORE PRINCIPLE

The system should deliver a usable stream at the required location after a credible fire has already affected normal access, power or machinery-space conditions.

Safety

Firefighting can expose crew to heat, smoke, electrical hazards, unstable compartments and contaminated water. Do not enter a fire space or operate unfamiliar valves and pumps without a plan, escape route and suitable protective equipment.

SYSTEM ARCHITECTURE

From the sea suction to the nozzle

Every stage can restrict final performance. A large pump cannot compensate for a shut valve, blocked strainer, air leak, damaged hose, undersized main or nozzle that cannot be controlled.




Layer	Purpose	Owner focus
Sea supply	A reliable source of water through an open, clear and structurally sound intake.	Know the suction valve, strainer, shared sea chest and risk of blockage or fire exposure.
Pump and driver	Produces flow against the resistance of pipework, height, hose and nozzle.	Identify power source, priming method, remote start and actual loaded performance.
Fire main	Carries pressurised water to hydrants and branches.	Inspect corrosion, drains, isolation valves, supports and vulnerable sections.
Hydrants and hoses	Allow the crew to connect and reach protected areas.	Confirm compatibility, hose length, access, cabinet condition and operating space.
Nozzle and application	Shapes the stream for cooling, protection or direct attack.	Know shut-off, spray/jet control, reaction force and safe handling.
Backup supply	Provides water if the normal pump, suction or compartment is unavailable.	Confirm genuine separation and demonstrate useful delivery, not merely that it starts.

PRESSURE AT THE NOZZLE MATTERS	Pump discharge pressure alone does not prove useful firefighting performance. Test the most remote or demanding hydrant with the hose and nozzle actually intended for use.
--------------------------------	---

MAIN COMPONENTS

What owners should be able to identify

A clear fire-main plan should show sea suctions, pumps, changeover valves, ring-main or branch pipework, hydrants, hoses, nozzles, drains, remote controls and any emergency connection.



Labels should identify the normal route and the fastest safe alternative during a fire.

Component or area	Why it matters	Owner focus
Sea suction and strainer	Controls water entry and protects the pump from debris.	Access, valve position, strainer condition, priming and vulnerability to fire or flooding.
Primary fire pump	Provides normal fire-main pressure and flow.	Driver, rated duty, remote start, seal condition and operating current/temperature.
Emergency or alternate pump	Provides supply after loss of the primary arrangement.	Separation of location, suction, power, control and discharge connection.
Fire main and isolating valves	Distributes water and allows damaged sections to be isolated.	Material, corrosion, support, drains, valve positions and ring-main integrity.
Hydrants, hoses and couplings	Provide connection and reach to intended spaces.	Compatibility, hose condition, cabinet access, washers and unobstructed deployment.
Nozzles and applicators	Control stream, spray pattern and shut-off at the hose end.	Operation under pressure, blockage, reaction force and suitability for intended use.

ACCESS IS PART OF THE SYSTEM	A hydrant behind stored gear, a seized cabinet or a hose that cannot be run through a doorway can remove practical coverage even when the pump and main are healthy.
------------------------------	--

ARRANGEMENT AND CAPABILITY

Dedicated, shared and emergency pumping arrangements

A yacht may use a dedicated fire pump, a general-service pump connected to the fire main, an engine-driven pump, a portable pump or a combination. The arrangement should remain usable after a credible machinery-space fire.

DEDICATED PUMP
Purpose-built supply with known duty

SHARED PUMP
General-service duty may create availability conflict

EMERGENCY PUMP
Separate location, power and suction where possible

PORTABLE PUMP
Flexible backup requiring rapid deployment

Two pumps are not independent if one fire, valve, sea chest, switchboard or access route removes both.

Area	What matters	Owner focus
Dedicated pump	Usually easier to keep ready and test against a defined duty.	Confirm it is not left isolated, unprimed or dependent on an inaccessible space.
General-service/shared pump	May serve bilge, washdown or cooling duties as well as fire main.	Understand changeover, priority and whether simultaneous demand is possible.
Emergency pump	Should preserve firefighting after loss of normal machinery-space services.	Check location, independent suction, starting source, fuel/power and discharge route.
Ring main versus branch main	A ring can preserve supply after one section is isolated; a branch may be simpler.	Know isolation-valve positions and what coverage is lost with each section shut.
Portable pump	Can supply a hose or emergency connection from deck or another water source.	Weight, priming, fuel, hose compatibility, sea state and realistic deployment time.
Shore or external connection	May allow assistance to pressurise the main in harbour or alongside.	Connection standard, non-return/isolation, pressure limits and clear identification.

DO NOT COUNT SHARED EQUIPMENT TWICE

A pump listed as both bilge and fire backup cannot necessarily perform both duties during the same flooding or fire event.

OPERATION AND CONTROL

Starting, priming and controlling the fire main

The crew should know how to establish pressure from normal and emergency stations, confirm the selected suction and discharge path, and deploy a hose without losing control of the nozzle.



Area	What matters	Owner focus
Priming	Some pumps must be flooded or primed before producing flow.	Know whether the pump self-primers, has a priming device or depends on intake position.
Remote start	Allows the pump to be started without entering a dangerous space.	Confirm indication, stop arrangement and what happens if remote control power is lost.
Hydrant operation	Opening too quickly can create hose movement and pressure shock.	Secure hose, control nozzle, communicate and open valves progressively.
Jet and spray patterns	Solid stream reaches farther; spray can cool, protect and absorb heat.	Use the nozzle mode appropriate to conditions and crew capability.
Boundary cooling	Protects adjacent compartments, tanks or structure from heat spread.	Avoid unnecessary water accumulation and monitor drainage and stability.
Simultaneous demand	Multiple hoses reduce pressure and may exceed pump capability.	Know tested combinations, pump reserve and the priority hydrant locations.

WATER CREATES ITS OWN HAZARD	Large quantities of firefighting water can reduce stability, flood lower compartments or damage electrical systems. Drainage and accumulation must be monitored during prolonged use.
-------------------------------------	---

DEPENDENCIES AND RESILIENCE

What can remove both normal and backup capability

Fire-main redundancy should be judged against the fire itself. Heat, smoke, loss of power, a damaged sea chest or inaccessible controls may remove equipment that appeared independent on paper.

SHARED SEA CHEST

One blocked or damaged intake affects both pumps

SHARED POWER

One board, battery or control supply removes both

SHARED SPACE

Fire blocks access or damages both pumps

SHARED MAIN

One rupture or shut valve removes all hydrants

The useful question is not "How many pumps?" but "What remains after this compartment is untenable?"

Area	What matters	Owner focus
Sea suction	Fouling, debris, ice, damage or a closed valve can starve the pump.	Identify alternate suction and whether the fire pump shares cooling or bilge intakes.
Electrical supply	Normal and standby pumps may share one switchboard, cable route or control voltage.	Trace breakers, emergency supply and fire-resistant routing where applicable.
Driver cooling and ventilation	An engine or motor may trip in a hot or smoke-filled space.	Understand cooling, fuel, air supply and safe remote operation.
Fire-main section	A burst pipe or heat-damaged joint can dump pressure.	Know ring-main isolation and the hydrants remaining after each valve is closed.
Remote controls	A network or PLC fault may prevent start or give false position feedback.	Retain local/manual capability and clear status indication.
Crew and equipment access	Smoke or fire may block pump, hydrant or hose route.	Select stations and deployment routes that remain usable from a safe side of the incident.

SEPARATION MUST BE PHYSICAL AND FUNCTIONAL

Separate labels are not enough. Pumps should be assessed for common suction, power, controls, compartment, cable route and discharge-main failures.

MONITORING AND ALARMS

Knowing whether useful water is actually available

The system should give enough information to distinguish a running motor from a pump that is delivering useful pressure and flow.



A remote "pump running" lamp should be supported by pressure or flow evidence.

Observation	What it may indicate	Owner response
Motor runs but pressure is low	Closed valve, blocked suction, loss of prime, worn impeller or major leak.	Stop repeated dry running; check safe valve route and select alternate supply.
Pressure falls when hydrant opens	Pump capacity, blocked main, hose restriction or excessive simultaneous demand.	Reduce demand, verify nozzle/hose and test another hydrant.
Pump cycles or loses prime	Air leak, suction blockage, water level/heel effect or priming defect.	Protect pump from damage and investigate the intake path.
High motor current or temperature	Mechanical binding, blocked discharge, low voltage or pump overload.	Reduce load and isolate before damage progresses.
Pressure high with little stream	Closed downstream valve, blocked hose/nozzle or faulty gauge.	Confirm the discharge route before assuming the main is ready.
Remote indication disagrees	Failed sensor, valve feedback, wiring or network.	Use physical verification and treat the unreliable indication as a defect.

TEST THE POINT OF USE	The most valuable evidence is a controllable stream from the most demanding hydrant while the selected pump, suction and power source are operating as intended.
-----------------------	--

FAILURE AWARENESS

Common weaknesses and warning signs

Fire-main failures often begin as poor pressure, a stiff valve, small leakage, pump seal drip, corroded pipework, damaged hose or a remote control that works intermittently.

BLOCKED SUCTION
Debris or fouling restricts water supply

PUMP / PRIME LOSS
Motor runs without useful water delivery

MAIN LEAK
Pressure is lost through corrosion or damage

HOSE / NOZZLE FAULT
Coverage or control is reduced at point of use

The first indication may be a weaker hose stream rather than a formal alarm.

Failure or evidence	Possible cause	Why it matters
Pump will not start	Lost power, failed starter, seized pump, emergency stop active or remote-control fault.	No water supply unless an alternate pump can be selected quickly.
Pump runs dry or will not prime	Closed suction, air leak, blocked strainer or failed priming device.	Rapid pump damage and false confidence from a running indication.
Low pressure or flow	Worn impeller, open bypass, blocked pipe, leak or incorrect valve lineup.	Hose stream may not reach, cool or control the fire.
Fire-main corrosion or rupture	Internal/external corrosion, freezing, vibration or unsupported pipework.	Large water loss and possible flooding while pressure collapses.
Hose, coupling or nozzle failure	Age, abrasion, damaged washer, incompatible coupling or blockage.	Crew lose reach or nozzle control when time is critical.
Emergency pump unavailable	Flat battery, stale fuel, inaccessible suction or untested connection.	Apparent redundancy disappears after normal machinery-space loss.

DO NOT NORMALISE CHANGE

A pump that “starts every time” but has never supplied the furthest hydrant under load has not demonstrated readiness.

EMERGENCY RESPONSE

Using the system without increasing the danger

Fire-main operation should support the vessel fire plan. Priorities are to raise the alarm, protect escape, stop fuel and ventilation as appropriate, establish water from a safe location and avoid uncontrolled water accumulation.

ALARM / ASSESS

Identify location, fuel and safe access

ISOLATE ESCALATION

Fuel, ventilation and electrical hazards

ESTABLISH WATER

Start safest available pump and confirm pressure

ATTACK / COOL

Use correct approach and maintain escape route

MONITOR / ESCALATE

Watch spread, drainage and request assistance

Situation or stage	Immediate thinking	Avoid
Smoke or fire near normal pump	Use remote start or independent pump from a safe station.	Entering the machinery space merely to start or prime the pump.
No pressure after start	Check safe valve lineup and select alternate suction/pump.	Allowing the pump to run dry or repeatedly resetting protection.
Hose crew cannot control nozzle	Reduce pressure or close nozzle; add crew and secure footing.	Opening hydrant fully before the nozzle team is ready.
Boundary cooling required	Apply controlled spray to threatened structure and monitor temperatures.	Flooding compartments or directing water into electrical equipment unnecessarily.
Fire-main section ruptures	Isolate the damaged section and use the ring/alternate route if fitted.	Leaving a major leak open and assuming a larger pump will compensate.
Fixed suppression released	Use the fire main for external boundary cooling and re-ignition control as directed.	Opening the protected space prematurely and releasing the agent concentration.


PROTECT THE ESCAPE ROUTE

A hose team should not advance beyond a point from which heat, smoke, hose failure or loss of water would prevent retreat.

TESTING AND DEMONSTRATION

Demonstrating pressure, reach and alternate supply

Testing should prove the complete route from suction to nozzle. It should also show that remote controls, alternate pumps and isolation valves work in the configuration expected during an emergency.



Test	What it demonstrates	Limitations / owner focus
Pump run test	Confirms starting, priming, seal condition and stable operation.	A short no-flow run does not prove firefighting capacity.
Remote-start test	Confirms safe-station control and indication.	Verify the pump actually delivers pressure, not only that the starter operates.
Remote hydrant test	Shows pressure, hose deployment and nozzle control at the demanding location.	Use safe discharge arrangements and record source/pump configuration.
Two-hydrant or design-duty test	Demonstrates simultaneous demand where the vessel plan expects it.	Requires adequate drainage, crew and specialist oversight where appropriate.
Emergency-pump test	Proves independent starting, suction and connection to the main.	Test after isolating relevant normal dependencies under a controlled procedure.
Isolation-valve exercise	Shows a damaged main section can be isolated while preserving coverage.	Restore and verify the normal lineup afterwards.

RESTORATION IS PART OF THE DRILL

Hoses should be drained and dried as appropriate, cabinets restowed, pump cooling checked and every valve returned to the documented normal position.

MAINTENANCE STRATEGY

Keeping water delivery dependable

Maintenance should preserve suction, pump condition, pipe integrity, valve movement, hose strength, nozzle operation and remote control. Records should show loaded performance, not only calendar servicing.

Area	Good maintenance evidence	Why it matters
Sea suction and strainer	Clean condition, operable valve, sound seals and known priming arrangement.	Prevents starvation, air ingress and pump damage.
Pump and driver	Service hours, seals, bearings, impeller, belt/coupling, current and temperature trend.	Maintains reliable start and rated duty.
Fire main and valves	Corrosion inspection, supports, drains, pressure/leak test and valve exercise.	Limits rupture, hidden leakage and seized isolation points.
Hydrants and couplings	Caps, threads, washers, valves and identification in good condition.	Allows fast connection without leakage or incompatibility.
Hoses and nozzles	Correct length/type, inspection, test status, dry storage and functional nozzle.	Preserves reach and controllability under pressure.
Remote start and alarms	Functional test, labels, power supply and feedback verified.	Supports operation when the pump compartment is unsafe.

Owner-level routine

- Keep suction and hydrant areas clear and immediately accessible.
- Run pumps regularly enough to identify priming, seal and starting problems.
- Inspect hoses after drills for abrasion, coupling movement and water retention.
- Record pressure or flow at repeatable hydrants and compare trends.
- Review the system after pipework, sea-chest, electrical or machinery-space modifications.

WORK TO REFER	Pressure testing, hose certification, pump overhaul, electrical starter work, fire-main repair and statutory or coding verification should be completed by competent specialists.
---------------	---

RECORDS, SPARES AND SUPPORTABILITY

Being able to operate and repair the system away from support

Useful provision combines service parts with simple operating information. The crew should be able to identify pump, suction, main and hydrant routes without searching through several unrelated manuals.

Area	Useful evidence or provision	Why it matters
System plan	Current fire-main drawing showing pumps, suctions, ring or branch sections and hydrants.	Speeds valve selection and damage isolation.
Test records	Pump, hydrant, pressure or flow and emergency-source test results.	Demonstrates real capability and identifies decline.
Pump spares	Manufacturer-approved seal, impeller, gasket, belt/coupling and priming parts as appropriate.	Supports realistic owner or technician recovery.
Hose hardware	Correct washers, caps, couplings, nozzle spares and repair items.	Prevents small defects making a hose unusable.
Portable backup	Pump, fuel or power, suction and discharge hoses with compatible connections.	Provides a genuine alternative only if it can be deployed quickly.
Specialist support	Pump, fire-service and pipework contacts in the intended cruising region.	Reduces delay when repair exceeds owner competence.

Practical onboard provision

- Fire-main diagram and one-page start or valve sequence at the safe operating station.
- Correct hose washers, blanking caps, coupling tools and selected nozzle parts.
- Pump-specific service items and the tools required for approved routine work.
- Portable lighting and communications for hose deployment and machinery monitoring.
- Records of hose tests, pump performance and changes to pipework or controls.

COMPATIBILITY MATTERS	A spare hose or portable pump is useful only if its couplings, diameter, pressure rating, suction arrangement and power source match the yacht.
-----------------------	---

BUYER AND SURVEY PERSPECTIVE

Assessing real firefighting capability rather than equipment count

A buyer should look beyond the presence of a pump and hose. Condition, coverage, separation, performance records, access and crew-operable controls determine whether the installation is credible.

Area	Questions or evidence
Pump arrangement	Is the primary pump dedicated or shared, and what independent emergency source remains after a machinery-space fire?
Performance	Is useful pressure or flow demonstrated at the most remote hydrant and under expected simultaneous demand?
Sea supply	Are suction, valves and strainers accessible, labelled and separated from common failure where practical?
Fire main	Is pipework free from significant corrosion, leakage, unsupported runs and undocumented alterations?
Hydrants and hoses	Do hose lengths, couplings and nozzle types provide practical coverage without blocked routes?
Remote operation	Can pumps and relevant isolation be controlled from a safe location with reliable feedback?
Records and compliance	Do servicing, testing and any flag or coding requirements match the current installation and cruising plan?

Evidence worth requesting

- Current fire-control and fire-main plans.
- Pump curves or rated duty and recent loaded test results.
- Hose inspection or pressure-test records and nozzle inventory.
- Details of shared sea chests, switchboards and control supplies.
- Defect, corrosion and pipe-repair history.

A CLEAN CABINET PROVES LITTLE

A recently replaced hose cannot compensate for a seized hydrant, blocked suction or emergency pump that has never been connected to the main.

OFFSHORE READINESS

Questions before relying on the fire main offshore

A ready system can establish water quickly, maintain a controllable stream at the required location and preserve an alternative after loss of normal machinery-space services.

Area	Question to resolve
Normal operation	Which pump, suction and valve route normally pressurise the main?
Emergency supply	What remains after fire or flooding makes the main pump space inaccessible?
Coverage	Can each high-risk space be reached with a controllable hose stream from a safe approach?
Power and fuel	Are emergency starting batteries, fuel and control supplies independent enough?
Damage isolation	Can a ruptured main section be isolated without losing every hydrant?
Crew capability	Can more than one person start the system and deploy a hose safely?

Quick readiness check

	Readiness statement
☐	I can identify normal and emergency pumps, suction, main valves, hydrants and hoses.
☐	A useful stream has been demonstrated at the most demanding hydrant.
☐	Remote start and local or manual fallback are labelled and functional.
☐	Emergency supply does not share every critical dependency with the normal pump.
☐	Hoses, couplings, nozzles and cabinets are accessible and serviceable.
☐	There are no unresolved leaks, low-pressure symptoms, seized valves or priming faults.
☐	The crew understand boundary cooling, water accumulation and safe hose handling.
☐	Test records, system drawings, selected spares and specialist contacts are available.

KEY TAKEAWAY

A dependable fire-main system is not defined by pump size alone. It combines a reliable water source, demonstrated pressure and flow, accessible distribution, genuine emergency supply and trained crew response.

Guidance to consult

Use the current vessel fire-control plan, fire-main drawing and the installed pump, hose and nozzle manufacturers' instructions, together with applicable flag-state, coding, class, insurer and fire-system service requirements.

Understanding Yacht Systems

Practical guides for owners, buyers
and offshore cruising crews.

AMTG-031

Understanding Fire Pumps and Fire Mains

RELATED GUIDES

AMTG-006 Understanding Fire Detection and Suppression Systems
AMTG-030 Understanding Seacocks and Through-Hull Fittings
AMTG-032 Understanding Emergency Shutdown Systems
AMTG-033 Understanding Fixed and Portable Firefighting Equipment
AMTG-034 Understanding Emergency Power Systems
AMTG-025 Understanding Load Shedding and Blackout Recovery

ABOUT ABSOLUTE MARINE

Independent technical advice for explorer yacht owners,
buyers and offshore cruising yacht owners.

Survey Report Reviews | Offshore Readiness Reviews
Reliability | Risk | Readiness

absolute-marine.co.uk

info@absolute-marine.co.uk