

Understanding Marine Diesel Engines



An owner's guide to combustion, supporting systems, operation and offshore reliability

A diesel engine is more than the engine block.

Reliable propulsion depends on clean fuel, air, lubrication, cooling and sound operation.

Absolute Marine

Commercial thinking for private cruising.



FUEL | AIR | COMPRESSION | POWER

GUIDE OVERVIEW

What a marine diesel engine is designed to do

A marine diesel engine converts the chemical energy in fuel into controlled crankshaft power for propulsion or auxiliary generation. Reliable operation depends on the engine and every system that supplies, protects, cools and controls it.

SCOPE	This guide focuses on four-stroke marine diesel engines used for yacht propulsion. It explains owner-level principles rather than overhaul procedures. Fuel, cooling, exhaust, lubrication, gearboxes and shaft systems are also covered in separate guides.
-------	--

By the end of this guide, you should be able to:

- Explain the four-stroke diesel cycle and the supporting systems needed for combustion.
- Identify the principal engine components, service points, sensors and external connections.
- Recognise changes in temperature, pressure, smoke, vibration, sound and fluid condition.
- Understand sensible start-up, loading, shutdown and low-load operating practices.
- Ask better questions during purchase, survey, maintenance and offshore preparation.

CORE PRINCIPLE	An engine rarely fails as an isolated block of metal. Loss of clean fuel, air, oil, cooling, electrical supply or exhaust flow can stop an otherwise healthy engine.
----------------	--


Safety

Engines contain hot surfaces, rotating machinery, high-pressure fuel, pressurised coolant, electricity and exhaust gases. Keep guards fitted, avoid loose clothing, isolate before work and never search for a high-pressure fuel leak with a hand.

COMBUSTION FUNDAMENTALS

How a four-stroke diesel produces power

A diesel engine draws in air, compresses it until it becomes hot, injects a measured quantity of fuel and uses the resulting combustion pressure to turn the crankshaft.



A four-stroke diesel completes this cycle once every two crankshaft revolutions.

What makes diesel combustion different

- No spark plug: Fuel ignites because it is injected into hot compressed air.
- Fuel controls load: More injected fuel creates more torque only while enough clean air and cooling are available.
- High compression: Pistons, rings, bearings, cylinder heads and fasteners operate under substantial load.
- Injection timing and atomisation: Fuel must enter at the correct time, pressure and spray pattern.
- Heat rejection: Only part of the fuel energy becomes useful shaft power; much becomes heat carried away by coolant, oil and exhaust.



Reliable output depends on every supporting system remaining within its normal operating range.

COMBUSTION BALANCE	Black smoke, rising exhaust temperature or failure to reach rated speed can indicate that fuel demand has exceeded available air or the propulsion system is imposing too much load.
-----------------------	--

ENGINE ARCHITECTURE

What owners should be able to identify

A clear engine-room walk-through should connect external systems to the internal engine: where fluids enter, where heat leaves, what rotates and what information reaches the helm.

Component or area	Function	Owner focus
Cylinder block and head	Contain cylinders, combustion chambers and coolant or oil passages.	Leaks, corrosion, fasteners, paint changes, access and previous major repair.
Pistons, rods and crankshaft	Convert combustion pressure into rotating torque.	Indirect condition through oil, blow-by, vibration, sound, compression and service history.
Valve gear and timing drive	Controls intake and exhaust flow in time with the crankshaft.	Adjustment intervals, belt/gear condition, abnormal noise and documented servicing.
Flywheel and bell housing	Smooth power pulses and connect the engine to the gearbox.	Guarding, fasteners, oil leakage, starter engagement and alignment evidence.
Mounts and beds	Support the engine and control vibration while maintaining alignment.	Compression, cracking, oil contamination, loose fasteners, corrosion and movement.
External service points	Provide access to filters, belts, pumps, fluids, drains and sensors.	Safe access underway, labels, correct tools and no dismantling of unrelated equipment.
Sensors and wiring	Report temperature, pressure, speed, position and fault information.	Connector condition, chafe, heat exposure, alarm testing and spare sensor strategy.

Engine ratings


- Rated power depends on the manufacturer's stated duty, speed and environmental conditions.
 - A high-output intermittent rating is not the same as a continuous-duty rating.
 - The installation must allow the engine to reach its specified operating speed without sustained overload.
 - Age and operating hours matter less than condition, loading, maintenance and supportability.
- ACCESS IS RELIABILITY

A service point that cannot be reached safely at sea is not merely inconvenient. Poor access can turn a routine filter, belt or leak response into loss of propulsion.

FUEL AND INJECTION

Delivering clean fuel at the correct pressure and time

Modern injection equipment works to fine clearances. Water, debris, air or incorrect fuel can stop the engine, damage expensive components or create intermittent faults that are difficult to diagnose.



Area	What can change	Owner focus
Tank and supply valves	Contamination, wrong tank selection, blocked pickup or closed valve.	Known valve plan, usable fuel, venting, return routing and emergency isolation.
Primary filter / separator	Water and solids accumulate; restriction rises.	Drain safely, monitor restriction or vacuum, carry correct elements and know changeover procedure.
Lift pump and low-pressure lines	Air ingress, weak delivery, hose collapse or leakage.	Prime, fittings, flexible hose condition, return fuel and evidence of bubbles.
Final engine filter	Fine contamination reaches the engine or filter restriction limits supply.	Correct element, change interval, cleanliness during replacement and bleeding procedure.
High-pressure pump / common rail	Wear, contaminated fuel, pressure-control faults or leakage.	Specialist work, fault codes, correct fuel and strict cleanliness.
Injectors	Spray pattern, opening behaviour or sealing deteriorates.	Hard starting, smoke, knock, uneven temperatures, fuel dilution and service records.

HIGH-PRESSURE INJECTION HAZARD

A pinhole fuel leak can penetrate skin and cause severe injury. Do not use fingers or bare hands to locate a leak; shut down and obtain urgent medical attention after suspected injection.


Fuel-related engine behaviour

Loss of power under load, surging, repeated filter blockage or hard restarting after a filter change often points to supply restriction, air ingress, contamination or an incorrect valve path before it points to internal engine failure.

AIR INTAKE AND TURBOCHARGING

Supplying clean, cool combustion air

A diesel needs a large volume of air. Engine-room ventilation, air filters, turbochargers and charge-air coolers work together; restriction or heat reduces the oxygen available for clean combustion.



Component	Purpose	Owner focus
Engine-room ventilation	Supplies combustion air and removes radiated heat.	Inlet/outlet condition, fans, dampers, filters, pressure, temperature and obstruction by stores.
Air filter or silencer	Protects compressor and cylinders while reducing intake noise.	Restriction, cleanliness, oil contamination, secure housing and replacement interval.
Turbocharger	Uses exhaust energy to compress intake air.	Whine, rubbing, oil leakage, shaft condition, wastegate/VGT function and cool-down guidance.
Charge-air cooler	Reduces compressed-air temperature and increases density.	Seawater/coolant flow, fouling, condensate drains, internal leakage and cleaning history.
Intake hoses and clamps	Carry compressed air without leakage or collapse.	Softness, oil, delamination, chafe, loose clamps and hidden underside condition.
Boost and air-temperature sensors	Help controls and monitoring assess engine load.	Plausibility, wiring, fouling and comparison with normal load readings.

AIR AND FUEL MUST MATCH

Adding fuel cannot create power without enough air. Black smoke, high exhaust temperature or low maximum speed may be caused by intake restriction, charge-air leakage, turbo faults or propulsion overload.

Engine-room temperature

Hot intake air reduces density and raises thermal stress. Compare machinery-space temperature with the manufacturer's limits and investigate failed fans, closed dampers or blocked ventilation rather than accepting heat as normal.

LUBRICATION

Maintaining an oil film and carrying heat away

Engine oil separates moving surfaces, cools bearings and pistons, suspends contaminants and protects against corrosion. Correct type, level, pressure, temperature and change history all matter.



Pressure is an indicator of resistance and flow condition; it is not a complete measure of oil quality.

Area	What to watch	Why it matters
Oil level	Falling, rising or inconsistent dipstick reading.	Loss suggests leakage or consumption; rise may indicate fuel or coolant contamination.
Oil pressure	Cold, warm-idle and loaded readings compared with the engine baseline.	A sudden fall can threaten bearings; sensor faults must be distinguished from real loss quickly.
Oil temperature	Trend with load, coolant temperature and engine-room condition.	High temperature reduces viscosity and may indicate cooling or overload problems.
Filter and bypass	Correct element, change interval, leakage and evidence of contamination.	A restricted filter may bypass unfiltered oil depending on design.
Breather / crankcase ventilation	Excess mist, restriction, oil carryover or abnormal pressure.	Can reveal blow-by, blocked ventilation or excessive oil level.
Oil cooler and lines	Leakage, corrosion, hose condition and water/oil cross-contamination.	Failure can remove lubrication or contaminate the cooling system.

Oil analysis

- Trend samples taken consistently can reveal wear metals, fuel dilution, coolant, soot and contamination.
- One result is less useful without engine hours, oil hours, top-up quantity and previous samples.
- A normal analysis does not replace inspection, pressure monitoring or correct service intervals.
- Unexpected results should be interpreted with the engine manufacturer or a competent specialist.

LOW-PRESSURE ALARM

Treat a genuine low-oil-pressure alarm as urgent. Reducing load may not protect an engine with lost oil supply; follow the approved response and avoid restarting until the cause is understood.

COOLING

Controlling combustion and component temperature

Most yacht engines use a closed freshwater coolant loop cooled by seawater through a heat exchanger. Both loops must remain clear, leak-free and correctly filled.



Area	Common weakness	Owner focus
Seacock and strainer	Closed valve, fouling, air leak or blocked basket.	Open position, clear flow, gasket, accessible service and no shared-intake surprise.
Raw-water pump / impeller	Worn vanes, failed seal, damaged cam or poor prime.	Service history, spare impellers, missing-vane recovery and leakage from tell-tale holes.
Heat exchanger and coolers	Scale, debris, corrosion, zinc fragments or internal leakage.	Cleaning records, end-cap seals, anodes and temperature difference under load.
Freshwater pump and thermostat	Poor circulation, bearing/seal failure or incorrect temperature control.	Leakage, noise, belt/drive, stable warm-up and correct thermostat.
Coolant and expansion tank	Wrong mixture, air, contamination, low level or cap failure.	Cold level, concentration, age, pressure cap, hoses and evidence of combustion gas.
Hoses and clamps	Ageing, softness, internal collapse, chafe or loose connection.	Full-length inspection, hot/cold behaviour, spare hose and correct clamping.

OVERHEATING IS A SYMPTOM

Do not assume every high-temperature event is an impeller. Intake restriction, lost coolant, air lock, belt failure, fouled coolers, exhaust restriction and overload can produce similar alarms.

After an overheat

Allow safe cooling, identify fluid loss and inspect the complete cooling and exhaust path before restarting. Severe overheating may damage hoses, seals, cylinder-head components, oil and exhaust equipment even after temperature returns to normal.

EXHAUST

Removing hot gas without fire, flooding or back-pressure

The exhaust route must carry combustion gases safely out of the yacht while preventing hot-surface exposure, excessive restriction, seawater backflow and carbon-monoxide entry into accommodation.



Area	What can fail	Owner focus
Dry manifold and turbo outlet	Cracking, insulation failure, loose fasteners or gas leakage.	Soot marks, smell, heat damage, fasteners and fire-safe shielding.
Mixing elbow / injection point	Internal corrosion, carbon, restricted water or leakage.	Age, inspection history, material, back-pressure and separation from the turbo.
Wet exhaust hose	Heat damage, delamination, collapse, chafe or loose clamps.	Rated hose, support, bends, full-length access and evidence of overheating.
Waterlock / silencer	Cracking, flooding, poor drainage or inadequate capacity.	Mounting, drains, water lift, engine cranking limits and backflow protection.
Riser and outlet geometry	Following seas, heeling or installation geometry allows water towards engine.	Approved rise, anti-siphon protection, outlet condition and operating limits.
Engine-room and accommodation sealing	Exhaust gases or carbon monoxide enter occupied spaces.	Leaks, ventilation pressure, detector placement and alarm testing.

CRANKING CAN FLOOD AN ENGINE

Repeated starting attempts may pump seawater into a wet exhaust without enough exhaust gas to clear it. Follow the engine and exhaust manufacturer's failed-start procedure.


Exhaust observation

Water flow, smoke, steam, soot, smell and exhaust note should be observed at start-up and under load. A changed outlet pattern can provide earlier warning than the temperature alarm.

STARTING, CHARGING AND CONTROLS

What must happen before the engine can run

Starting requires adequate cranking speed, electrical continuity, control permission, fuel delivery and enough compression. A failure in the start circuit can mimic an engine problem.



Area	Common failure	Owner focus
Start battery bank	Low charge, sulphation, failed cell or loose connection.	Resting/cranking voltage, capacity test, terminal condition and separation from domestic loads.
Isolator, solenoid and cables	Resistance, corrosion, heat damage or intermittent contact.	Voltage drop, secure lugs, cable support and emergency parallel arrangement.
Starter motor	Worn contacts, solenoid, pinion or internal electrical/mechanical fault.	Cranking speed, sound, heat, engagement and service history.
ECU / shutdown circuit	Loss of supply, sensor fault, network issue or active protection.	Fault codes, emergency stop, local start, key switch and safe reset procedure.
Alternator and charging	Belt, regulator, wiring, diode or temperature failure.	Charge voltage/current, belt dust, heat, alarm, battery-sense wiring and spare belt.
Engine controls	Throttle, shift, station selection or electronic-command fault.	Local control, neutral interlock, station transfer and mechanical emergency operation where fitted.

Alarms and shutdowns

- Know which conditions generate a warning and which initiate automatic shutdown.
- An alarm proves the circuit only when sensors, wiring, display and audible device are all tested.
- Bypassing a shutdown may prevent immediate stoppage but can convert a manageable fault into major damage.
- Emergency-stop locations should be clear, guarded against accidental use and tested under the approved procedure.

LOCAL OPERATION	For offshore resilience, understand whether the engine can be started, stopped and controlled locally after loss of a bridge display, network or remote-control station.
------------------------	--

ENGINE INSTALLATION

Mounts, alignment, gearbox interface and propulsion load

The engine can be healthy while the installation overloads it. Mounts, alignment, gearbox, shaft line, propeller, hull condition and attached accessories all affect engine behaviour.

Area	Why it affects the engine	Owner focus
Flexible mounts and beds	Carry weight, react torque and maintain alignment while limiting vibration.	Height, compression, oil contamination, cracking, loose fasteners and engine movement.
Gearbox and coupling	Transmit torque and impose thrust or alignment loads.	Oil, temperature, shift quality, coupling fasteners, backlash and service records.
Shaft alignment	Misalignment increases bearing, coupling, seal and mount loads.	Vibration, coupling condition, bearing temperature and alignment after launch or mount work.
Propeller and hull condition	Fouling, damage or excessive pitch raises torque demand.	Maximum reachable rpm, black smoke, fuel burn, speed, vibration and recent underwater condition.
Power take-offs and hydraulics	Alternators, pumps and PTO loads consume engine power and add belt or bearing load.	When loads engage, overheating, belt condition, hydraulic pressure and effect on available propulsion.
Engine-room services	Ventilation, fuel, seawater, exhaust and electrical systems may be shared.	Single points of failure and consequences of isolating one engine or service.

UNDERLOAD

Prolonged light load may encourage deposits

NORMAL LOAD

Stable temperature and clean combustion

OVERLOAD

Excess fuel, heat, smoke and cylinder load

PROPULSION MATCH

Hull, propeller and gear ratio set demand

MAXIMUM SPEED IS DIAGNOSTIC	A correctly loaded propulsion engine should be able to reach the manufacturer's specified full-load speed under suitable test conditions. Failure to do so deserves investigation before sustained offshore use.
-----------------------------	--

OPERATING PRACTICE

Starting, warming, loading and shutting down

Good operation does not mean treating the engine gently at all times. It means bringing it to stable temperature, applying suitable load, monitoring it and avoiding practices that create unnecessary wear or deposits.

Stage	Good operating thinking	Avoid
Pre-start	Inspect fluids, bilges, leaks, valves, belts, filters and the area around rotating equipment.	Starting with closed seawater valves, tools left on machinery or unresolved leakage.
Start	Confirm prompt oil pressure, charging, cooling-water flow, normal smoke and stable idle.	Repeated long cranking, immediate high rpm or ignoring an abnormal start.
Warm-up	Use modest load once pressure is established so the complete engine warms progressively.	Long unloaded idling unless the manufacturer or operational situation requires it.
Cruising load	Operate within the approved speed/load range and compare readings with the baseline.	Sustained overload, continuous black smoke or relying on one gauge alone.
Periodic higher load	Where approved, use sufficient load to confirm performance and reduce light-load deposits.	A sudden maximum-load test without warm-up or after a known defect.
Cool-down and stop	Reduce load, allow temperatures to stabilise as specified, then stop and inspect.	Extended unnecessary idling or immediate stop after severe load where guidance requires cool-down.

Low-load operation

- Prolonged light load can prevent full operating temperature and contribute to soot, deposits or wet exhaust.
- The correct response depends on engine design, duty rating and manufacturer guidance.
- A displacement yacht may legitimately operate below maximum power for long periods, but the propeller and engine still need a suitable load relationship.
- Trend exhaust appearance, oil condition, temperature and performance rather than applying a universal percentage rule.

DO NOT OPERATE BY FOLKLORE	Warm-up, cool-down, maximum-load checks and permitted continuous load vary between engines. Use the installed manufacturer's instructions and the actual duty rating.
-----------------------------------	---

MONITORING AND CONDITION CLUES

Learning what normal looks like

Engine condition is easier to judge from trends than isolated numbers. Record stable readings at repeatable speeds and investigate changes before they reach alarm limits.



Smoke colour is a clue, not a diagnosis; load, temperature, duration and engine condition all matter.

Observation	Useful interpretation	Owner action
Coolant temperature	Trend with rpm, load, seawater temperature and engine-room heat.	Investigate a gradual rise, instability or unequal twin-engine readings.
Oil pressure	Compare cold, warm-idle and loaded values.	Treat sudden loss urgently; verify sensor only after protecting the engine.
Exhaust temperature / smoke	Shows combustion balance, load and possible cylinder inequality.	Record when it appears, duration, load, colour and whether one bank/cylinder differs.
Boost and rpm	Relate air delivery and engine speed to fuel demand and vessel performance.	Investigate falling boost, low maximum rpm, surging or unexpected fuel use.
Vibration and sound	Changes can arise from mounts, misfire, accessories, shaft line or internal damage.	Compare at fixed rpm and note whether it changes in/out of gear or with attached loads.
Crankcase blow-by	Some vapour is normal; change may indicate ring wear, overfill or breather restriction.	Trend against load, oil use and engine history; avoid unsafe opening of running equipment.
Fluid consumption	Oil, coolant and fuel trends reveal leaks, burning, dilution or loading changes.	Record top-ups by quantity and hours rather than describing use as 'normal'.


COMPARE TWINS CAREFULLY

Two engines may have different sensors or installation conditions, but a persistent difference in temperature, boost, smoke, sound or fuel use is valuable evidence and deserves explanation.

FAILURE AWARENESS

Common weaknesses and immediate response

Most engine failures begin with a change in sound, smoke, pressure, temperature, output or fluid condition. The first objective is to protect people and prevent a small fault becoming major damage.



Symptom or failure	Possible causes	Immediate thinking
Engine stops or loses power	Fuel restriction, air, control shutdown, blocked exhaust, overheating or mechanical fault.	Stabilise vessel, note alarms, verify fuel/control state and avoid repeated restarting without cause.
High coolant temperature	Lost raw-water flow, coolant loss, belt/pump fault, fouling, air lock or overload.	Reduce load or stop as required; inspect flow, leaks and the full cooling/exhaust path after safe cooling.
Low oil pressure	Low level, pump/pickup fault, severe leak, bearing damage, hot/thin oil or sensor fault.	Protect the engine immediately and do not assume an instrument fault until real pressure loss is excluded.
Black smoke / cannot reach rpm	Overload, fouled propeller, restricted air/exhaust, turbo or injection fault.	Reduce load; compare boost, speed, exhaust and underwater condition.
White or blue smoke	Cold misfire, injector/compression fault, oil burning, coolant or water vapour.	Note duration, smell, fluid levels and whether it clears; obtain diagnosis before heavy loading.
Sudden vibration or knock	Propeller/shaft damage, mount or coupling failure, misfire, accessory or internal fault.	Reduce load or stop; do not continue until external and internal risks are assessed.
Fuel, oil, coolant or exhaust leak	Hose, seal, fitting, cooler, injection line, gasket or structural failure.	Address fire, injection, toxic-gas and fluid-loss risks before attempting recovery.

DO NOT NORMALISE IT

A familiar alarm, recurring coolant top-up, repeated filter blockage, new vibration or smoke that 'clears eventually' is evidence of an unresolved defect.

Restart decision

A restart may restore propulsion after a simple control or fuel issue, but it can worsen lubrication loss, overheating, water ingestion or internal damage. The decision should be based on the fault evidence, environment and remaining options.

MAINTENANCE STRATEGY

Servicing, records, condition monitoring and spares

Good engine maintenance combines scheduled work with inspection and trend evidence. Replacing parts by hours alone does not explain repeated failures, fluid loss or changing performance.

Area	Good maintenance evidence	Why it matters
Daily / pre-use checks	Recorded levels, leaks, belt/hoses, bilges, strainers, filters and normal start observations.	Finds change before alarm or passage failure.
Scheduled servicing	Hours and calendar intervals, correct parts/fluids, valve or injector work and major-service evidence.	Confirms critical work rather than only an invoice marked 'engine serviced'.
Oil and coolant trends	Analysis, concentration, top-ups, contamination and change intervals.	Reveals wear, dilution, corrosion and hidden fluid exchange.
Cooling and exhaust history	Impellers, coolers, heat exchanger, mixing elbow, hoses and back-pressure checks.	These systems commonly stop otherwise healthy engines.
Performance records	Speed, rpm, temperatures, pressure, boost, fuel use and smoke under repeatable load.	Shows gradual loss of performance and installation overload.
Major repair provenance	Reason, scope, measurements, parts, specialist, warranty and post-repair test.	A rebuilt component is only as useful as the evidence explaining what was done.

Offshore spares and tools

- Correct fuel and oil filters, belts, raw-water impellers, seals and service fluids.
- Selected hoses, clamps, electrical protection, sensors or relays where owner replacement is realistic.
- Fuel-bleeding, filter-change and raw-water recovery tools suited to the actual installation.
- Absorbent materials, leak-control items, lighting and communications for safe engine-room work.
- Current manuals, diagrams, part numbers, fault-code information and specialist contacts.

SPARES MUST MATCH CAPABILITY

Carrying a major component adds little resilience if it cannot be fitted safely with the available tools, access, knowledge and sea conditions. Prioritise realistic failure recovery.

Work to refer

Injection-system work, internal engine repair, compression/leak-down diagnosis, turbo overhaul, cylinder-head work, alignment, control-system configuration and persistent safety faults should be handled by competent specialists.

OFFSHORE READINESS

Buyer questions and readiness checklist

An offshore-ready engine is not one that merely starts at the dock. It has demonstrated reliable performance under load, current maintenance, known limitations and a crew able to respond to foreseeable supporting-system faults.

Area	Questions for purchase or survey
Identity and rating	Are model, serial number, duty rating, rated speed, hours and electronic data consistent with the vessel and records?
History	Do invoices, logs, oil analysis and major-repair records explain how the engine has been operated and maintained?
Cold start and idle	Does it start from cold without excessive cranking, smoke, knock, leakage or unstable pressure?
Loaded trial	Does it reach expected rpm, speed, temperatures, pressure, boost and exhaust condition under realistic load?
Installation	Are fuel, air, cooling, exhaust, electrical, mounts, gearbox and shaft interfaces credible and accessible?
Supportability	Are parts, diagnostic tools, specialists, manuals and software support realistically available?
Degraded operation	What remains after one engine, fuel source, starter bank, seawater intake, control station or exhaust route fails?

Quick readiness check

	Readiness statement
	I can identify the engine's fuel, air, lubrication, cooling, exhaust and electrical paths.
	Normal cold-start, warm-idle and loaded readings, sounds, smoke and vibration are known.
	The engine has demonstrated suitable rpm and stable performance under realistic propulsion load.
	There are no unresolved leaks, alarms, repeated filter problems, overheating or abnormal fluid use.
	Service history, major work, duty rating, manuals and diagnostic information are available.
	Critical filters, belts, impellers, fluids, tools and recovery procedures match the installation.
	Shared dependencies and local start, stop or control arrangements are understood.
	More than one person knows the immediate response to fuel, cooling, oil-pressure and control faults.

KEY TAKEAWAY

A dependable marine diesel engine combines sound mechanical condition with clean fuel and air, reliable lubrication and cooling, safe exhaust, suitable propulsion loading, disciplined operation and early recognition of change.

Guidance to consult

Use the installed engine, gearbox, control, cooling and exhaust manufacturers' current operating and service instructions, together with applicable flag-state, coding, class, insurance, emissions and yard requirements.

Understanding Yacht Systems

Practical guides for owners, buyers
and offshore cruising crews.

AMTG-013

Understanding Marine Diesel Engines

RELATED GUIDES

AMTG-014 Understanding Engine Cooling Systems
AMTG-015 Understanding Exhaust Systems
AMTG-016 Understanding Gearboxes and Marine Transmissions
AMTG-017 Understanding Shaft Lines, Bearings and Propellers
AMTG-018 Understanding Engine-Room Ventilation
AMTG-019 Understanding Lubrication Systems
AMTG-020 Understanding Fuel Transfer and Day-Tank Arrangements

ABOUT ABSOLUTE MARINE

Independent technical advice for explorer yacht owners,
buyers and offshore cruising yacht owners.

Survey Report Reviews | Offshore Readiness Reviews
Reliability | Risk | Readiness

absolute-marine.co.uk

info@absolute-marine.co.uk