

Understanding Engine Cooling Systems


An owner's guide to coolant circulation, raw-water flow and overheating prevention

An engine can be mechanically healthy and still stop through loss of cooling.

Readiness depends on both circuits, not only the temperature gauge.

Absolute Marine

Commercial thinking for private cruising.



GUIDE OVERVIEW

What an engine cooling system is designed to do

The cooling system removes waste heat while keeping the engine within a controlled operating-temperature range. Most yacht installations use a treated closed-circuit coolant loop and a separate raw-seawater loop.

SCOPE	This guide focuses on indirect cooling systems commonly fitted to marine diesel propulsion engines. Keel cooling, direct seawater cooling and specialist arrangements are mentioned where relevant, but the installed engine and vessel drawings remain the primary reference.
-------	--

By the end of this guide, you should be able to:

- Trace the closed-circuit coolant and raw-water paths through the engine and exhaust.
- Identify pumps, thermostats, heat exchangers, tanks, hoses, strainers, anodes and monitoring points.
- Recognise restriction, coolant loss, air locks, impeller damage, fouling and exhaust-injection problems.
- Understand why coolant quality, pressure and correct bleeding matter.
- Ask better questions during purchase, survey, maintenance and offshore preparation.

CORE PRINCIPLE	Cooling reliability depends on heat transfer and fluid flow. A normal coolant level cannot compensate for lost seawater flow, and a new impeller cannot compensate for a blocked cooler or collapsing hose.
----------------	---


Safety

Hot coolant can remain pressurised after shutdown. Do not remove a pressure cap or open a hot circuit until the manufacturer's safe-cooling procedure has been followed. Seawater hoses and strainers below the waterline also create flooding risk.

SYSTEM ARCHITECTURE

How heat leaves the engine

Combustion heat moves into metal, coolant, oil and exhaust. The cooling system must circulate those fluids, transfer heat across clean surfaces and discharge it without introducing seawater into the engine.



The two circuits exchange heat but should remain physically separate inside the heat exchanger.

The two main circuits

- Closed-circuit coolant: Treated freshwater/antifreeze circulates through the engine, thermostat and heat exchanger.
- Raw water: Seawater enters through a seacock and strainer, passes through the pump and coolers, then normally joins the wet exhaust.
- Oil and charge-air cooling: Some engines place gearbox, engine-oil, fuel or charge-air coolers in the same raw-water path.
- Pressure and expansion: A cap and expansion arrangement control level change, boiling margin and recovery.
- Monitoring: Temperature, level, pressure, flow and exhaust observations provide evidence of change.

SHARED DEPENDENCIES	One restricted seacock, strainer or raw-water pump may affect the engine, gearbox, charge-air cooler and wet exhaust together. Trace the actual cooler order and every shared branch.
------------------------	---

Direct and keel-cooled engines

Some engines circulate seawater directly through the engine or reject heat through an external keel cooler. These arrangements change corrosion, winterisation and failure risks, but still depend on controlled flow, clean heat-transfer surfaces and correct fluid quality.

CLOSED-CIRCUIT COOLING

Coolant pump, thermostat and engine passages

The freshwater pump circulates treated coolant through the block, cylinder head and connected coolers. The thermostat controls the path so the engine reaches and maintains its intended operating temperature.



Coolant then returns to the pump; the expansion tank accommodates level change and trapped air.


Component	Function	Owner focus
Freshwater circulation pump	Moves coolant through the engine and heat exchanger.	Seal leakage, bearing noise, drive condition, weep hole and replacement history.
Thermostat	Controls warm-up and flow through the heat exchanger.	Correct temperature rating, stable warm-up, sticking, corrosion and replacement evidence.
Engine coolant passages	Carry heat away from cylinders, head and turbo or manifold where fitted.	Scale, corrosion, blocked passages, gasket leakage and evidence of previous overheating.
Bypass circuit	Maintains circulation before the thermostat opens.	Correct hose routing, restriction and no undocumented blanking or modification.
Temperature sender and alarm	Report engine temperature and warn before severe damage.	Sensor location, calibration, wiring, alarm test and comparison with an independent reading.
Heater or calorifier branch	Uses engine coolant to heat domestic water or accommodation.	Isolation, hose condition, air locks, elevation and consequences of a remote leak.

THERMOSTAT REMOVAL IS NOT A CURE	Running without the specified thermostat can alter flow distribution, extend warm-up and create local overheating. Diagnose the cause rather than treating temperature control as optional.
---	---

COOLANT AND PRESSURE

Protecting against corrosion, boiling and freezing

Engine coolant is a working fluid and a corrosion-control package. Correct type, concentration, age and system pressure protect metals, seals and heat-transfer surfaces.



Area	What can go wrong	Owner focus
Coolant specification	Wrong chemistry or unsuitable water attacks metals, seals or inhibitors.	Use the current manufacturer-approved product and compatible top-up mixture.
Concentration	Too weak reduces protection; too strong may reduce heat transfer or pump performance.	Test using the approved method and record the result, not only the colour.
Mixing coolants	Different additive packages can react, gel or lose protection.	Identify what is installed before topping up; flush correctly when changing chemistry.
Pressure cap	Weak seal, wrong rating or blocked recovery path changes pressure and boiling margin.	Correct rating, seal condition, neck, overflow hose and safe cold testing.
Expansion or header tank	Low level, air, blocked connection, cracking or inaccurate remote indication.	Cold level, mounting, visibility, cap, hose and evidence of repeated loss.
Coolant contamination	Oil, fuel, soot, rust, seawater or combustion gas enters the circuit.	Colour, film, deposits, pressure after cold start and laboratory testing where needed.


REPEATED TOP-UP IS A FAULT

Coolant is not normally consumed in the way fuel is. A falling level deserves explanation: external leakage, cap/recovery fault, heater circuit, cooler leak, gasket failure or overheating may be involved.

RAW-WATER SUPPLY

Seacocks, strainers, hoses and intake condition

The raw-water circuit begins below the waterline. It must deliver unrestricted seawater without air while remaining safely isolatable for inspection and emergency response.




Area	Common weakness	Owner focus
Hull intake and scoop	Fouling, paint, debris, poor orientation or aeration in certain speed/sea conditions.	Underwater inspection, grate/scoop design, recent fouling and behaviour under load.
Seacock	Seized, partly open, corroded, poorly supported or inaccessible.	Exercise, label, bonding/condition, handle position and emergency access.
Strainer	Blocked basket, leaking lid seal, cracked housing or trapped air.	Clean baseline, spare gasket, safe service with seacock closed and ability to prime.
Suction hose	Softening, internal collapse, delamination, chafe or air leakage.	Full-length inspection, vacuum suitability, clamps, bend radius and underside condition.
Shared intake manifold	One blockage or valve position affects more than one system.	Branch labels, valve plan, demand under simultaneous operation and single-point failure.
Strainer differential or vacuum	No instrument or no normal baseline hides gradual restriction.	Know clean and loaded readings where fitted; inspect after weed, debris or grounding risk.

AIR CAN LOOK LIKE BLOCKAGE	A loose strainer lid, suction-hose leak or intake emerging from the water in heavy motion can reduce flow without an obvious external leak. Bubbles and loss of prime matter.
----------------------------	---

RAW-WATER PUMP

Flexible impellers, pump drives and missing vanes

The common flexible-impeller pump relies on seawater for lubrication. Dry running, age, deformation, heat and poor pump condition can reduce flow long before every vane disappears.



A new impeller does not restore cooling if the intake, cover plate, cam, drive or downstream passage remains defective.

Area	What to inspect	Why it matters
Impeller vanes and hub	Cracks, permanent set, missing tips, separation and hardening.	Reduced displacement or sudden failure removes raw-water flow.
Cam and cover plate	Scoring, wear, corrosion, wrong gasket thickness and distortion.	A new impeller may still produce poor suction or flow.
Shaft seal and bearings	Water or oil from tell-tale holes, noise, movement and corrosion.	Leakage can damage the drive, contaminate engine oil or flood locally.
Pump drive	Belt, gear, coupling, key or fastener condition.	The impeller can be perfect while the pump does not turn correctly.
Prime and suction	Air in housing, closed valve, high lift, poor hose route or leaking gasket.	Dry running damages the impeller and may prevent self-priming.
Downstream fragments	Missing vanes lodged in cooler end caps, pipes or mixing elbow.	New parts do not restore flow until fragments and the original cause are removed.


Impeller replacement

- Confirm the correct part, rotation and vane orientation for the installed pump.
- Lubricate only with a product approved for the impeller and system.
- Inspect the cover, cam, shaft and seal rather than replacing the rubber alone.
- Account for every missing piece and check downstream coolers or passages.
- After restart, verify suction, leaks, exhaust-water flow and temperature under load.

HEAT EXCHANGERS AND COOLERS

Transferring heat without mixing the circuits

Tube bundles, plates or stacked coolers provide a barrier between fluids. Fouling reduces heat transfer; corrosion or seal failure can allow seawater, coolant, oil or charge air to cross that barrier.



Scale, debris, corrosion and internal leakage reduce heat transfer or contaminate one circuit with the other.

Equipment	Common condition issue	Owner focus
Main heat exchanger	Scale, debris, blocked tubes, corrosion, failed end-cap seals or internal leakage.	Cleaning interval, pressure test, end caps, anodes and coolant/seawater cross-contamination.
Charge-air cooler	Seawater fouling, oil film, condensate, tube leak or restricted air side.	Boost, intake temperature, cleaning history and water/oil evidence in air path.
Engine-oil cooler	Corrosion or seal failure mixes oil and cooling water.	Oil/coolant condition, pressure relationships, external leakage and replacement history.
Gearbox cooler	Restricted flow or internal failure overheats or contaminates transmission oil.	Oil colour/level, gearbox temperature and cooler position in the raw-water sequence.
Fuel cooler	Fouling, leakage or unsupported ageing component.	Fuel temperature, leak risk and whether the cooler remains required by the current system.
Sacrificial anodes	Consumed, coated, broken or incorrect anodes stop protecting cooler metals.	Correct material, inspection interval, fragment removal and electrical continuity where designed.

CLEANING NEEDS EVIDENCE	Chemical cleaning can remove deposits but may also expose weak metal or damage seals if the product and procedure are wrong. Record what was cleaned, how it was tested and what condition was found.
-------------------------	---

CIRCULATION FAULTS

Thermostats, air locks, hoses and remote branches

A system can contain enough coolant and still circulate poorly. Trapped air, a collapsed hose, incorrect thermostat, failed pump or badly routed remote branch can create local overheating.

FILL SLOWLY

Use approved coolant and correct fill point

VENT HIGH POINTS

Air collects above normal flow paths

WARM AND CHECK

Thermostat opening may change level

RECHECK COLD

Confirm stable level and no leakage

Condition	Possible clues	Why it matters
Air lock	Unstable temperature, heater not warming, sudden level change or poor circulation after service.	Air can stop local flow and expose hot surfaces or sensors to misleading conditions.
Thermostat stuck closed	Rapid overheat as load rises; heat exchanger remains relatively cool.	Coolant cannot reject heat through the normal route.
Thermostat stuck open	Slow warm-up, low operating temperature or poor heater performance.	Engine may not reach intended temperature and deposits or wear may increase.
Collapsed or delaminated hose	Temperature rises under load, hose changes shape or restriction is hidden internally.	A hose may look acceptable externally while limiting flow.
Remote calorifier/heater leak	Coolant loss away from engine, damp locker, smell or unexplained top-up.	A domestic branch can remove propulsion cooling fluid.
Incorrect bypass or valve position	System changed after refit or service; flow avoids the heat exchanger or branch.	Documentation and labels no longer match actual cooling performance.


BLEEDING IS INSTALLATION-SPECIFIC

Do not assume the expansion tank is automatically the highest point. Engines, calorifiers and remote heaters may need defined vent points or temporary procedures from the manufacturer.

EXHAUST COOLING AND BACKFLOW

Mixing elbows, wet exhausts and anti-siphon protection

Raw water normally leaves the cooling system by entering the exhaust downstream of the hot dry section. This cools the hose and silencer, but creates corrosion, restriction and water-ingestion risks.



Area	What can fail	Owner focus
Mixing elbow / injection point	Carbon, salt, corrosion, cracking or restricted water passage.	Age, material, inspection, back-pressure and external soot/rust staining.
Anti-siphon loop or vent	Blocked vent, wrong height, failed valve or poor hose route.	Location relative to waterline in all conditions and routine inspection.
Wet exhaust hose	Overheat, delamination, collapse, chafe or loose clamps.	Rated hose, full-length access, softness, blistering and evidence of previous dry running.
Waterlock / silencer	Crack, poor mounting, blocked drain or inadequate capacity.	Retained-water volume, failed-start procedure and backflow risk.
Outlet and transom geometry	Following sea or heeling drives water towards the engine.	Riser height, outlet condition and vessel-specific operating limitations.
Exhaust-water observation	Reduced flow, intermittent discharge, steam or changed note.	Establish normal appearance at idle and under load; investigate change before alarm.

REPEATED CRANKING CAN CAUSE WATER INGESTION

If the engine does not start, the raw-water pump may continue filling the wet exhaust without exhaust gas to clear it. Follow the engine and exhaust manufacturer's failed-start procedure.

MONITORING AND WARNING SIGNS

Learning how temperature and flow normally behave

Cooling-system condition is easier to judge from trends than a single alarm. Compare warm-up, loaded temperature, exhaust-water flow and twin-engine behaviour under repeatable conditions.



Observation	Possible interpretation	Owner response
Gradual temperature rise over months	Fouling, ageing impeller, scale, coolant deterioration or rising propulsion load.	Compare like-for-like conditions and inspect the complete heat-transfer chain.
Sudden high-temperature alarm	Lost raw-water flow, coolant loss, belt/pump failure, collapsed hose or severe overload.	Reduce load or stop as required; protect the engine before searching for the cause.
Normal gauge but little exhaust water	Early raw-water loss, sensor location delay or partial branch blockage.	Do not wait for coolant temperature to rise; inspect flow immediately.
Coolant level repeatedly falls	External leak, cap/recovery fault, heater branch, internal cooler leak or combustion-gas issue.	Record quantity and hours; pressure-test and diagnose rather than topping up indefinitely.
One engine runs hotter	Different fouling, load, sensor, propeller condition, air flow or cooler restriction.	Compare rpm, load, boost, exhaust and instrument accuracy before accepting the difference.
Steam, smell or paint change	Local leakage, hot spot, dry exhaust, belt slip or coolant contact with hot surfaces.	Inspect safely after shutdown and identify all secondary damage.

ALARM LIMITS ARE NOT TARGETS

Normal operation should provide margin below the alarm. A rising trend that remains technically below the threshold still deserves investigation.

Useful baseline records

Record coolant temperature, seawater temperature, rpm, vessel speed, engine load, exhaust-water appearance, strainer condition and any top-up. These details make later comparisons meaningful.

MAINTENANCE STRATEGY

Inspection, cleaning, records and spares

Cooling maintenance should preserve flow, heat transfer, corrosion protection and leak integrity. Replacing an impeller annually is useful, but it is not a complete cooling-system strategy.

Area	Good maintenance evidence	Why it matters
Coolant	Specification, concentration, test result, change date, quantity and contamination findings.	Confirms corrosion, freezing and boiling protection rather than colour alone.
Raw-water service	Impeller, cam, cover, seal, drive, strainer and hose condition recorded.	Shows whether flow was actually restored and missing fragments recovered.
Coolers and heat exchanger	Cleaning method, deposits found, anodes, seals and pressure-test result.	Demonstrates condition on both sides of the heat-transfer surface.
Thermostat and pump	Test or replacement, opening rating, leakage and bearing condition.	Prevents circulation faults being mistaken for fouling.
Exhaust injection	Mixing elbow, anti-siphon, hose, waterlock and outlet inspection.	Cooling failure can become exhaust fire, flooding or water ingestion.
Performance test	Stable loaded temperature, expected rpm, flow and no leakage after service.	A dockside idle test may not reveal restricted heat rejection.

Offshore spares and tools

- Correct impellers, cover gasket or O-ring, pump service parts and any dedicated puller.
- Approved coolant concentrate or premix, belts, selected hoses, clamps and pressure-cap spare where justified.
- Strainer lid seal, cleaning tools, temporary plugs and safe lighting for below-waterline work.
- Thermostat, temperature sender or relay only where owner replacement is realistic and documented.
- Manuals, flow diagrams, cooler order, refill/bleeding procedure and specialist contacts.

SERVICE AFTER THE SERVICE	Run the engine under representative load, recheck cold level after cooling and inspect every disturbed joint. Many failures follow maintenance because air, loose clamps or incorrect valve positions remain.
----------------------------------	---

OVERHEATING RESPONSE

Protecting the engine and preserving options

An overheating event is not one fault with one universal response. The urgency depends on temperature rise, alarms, fluid loss, exhaust-water flow, engine load and the surrounding navigational situation.



Evidence	Likely areas to consider	Response thinking
No or reduced exhaust water	Closed seacock, blocked intake/strainer, lost prime, impeller or downstream blockage.	Protect engine promptly; do not continue loading while waiting for temperature to rise.
Coolant visible in bilge	Hose, pump seal, cap, tank, heater branch, gasket or cooler failure.	Stop loss, avoid burns, assess remaining level and do not restart without adequate coolant and diagnosis.
Temperature rises only under load	Fouling, marginal flow, overload, hose collapse, thermostat or air-side heat problem.	Reduce load and investigate before resuming sustained passage power.
Temperature spikes after service	Air lock, wrong valve, incorrect thermostat, loose belt or poor refill.	Recheck the work and bleed using the approved procedure.
Steam or overheated wet exhaust	Raw-water loss or restricted mixing elbow while hot gas continues.	Address fire and hose damage risk; inspect the exhaust before restart.
Coolant pressurises rapidly from cold	Possible combustion-gas entry, severe air pocket or incorrect fill arrangement.	Do not repeatedly vent and top up; obtain competent diagnosis.

RESTART DECISIONS MATTER

A restart may be reasonable after a proven simple blockage or loose belt, but it can worsen coolant loss, water ingestion, cracked exhaust components or internal engine damage. Base the decision on evidence and remaining options.

After a severe overheat

Inspect oil and coolant condition, hoses, clamps, pump seals, exhaust components, belt drives and fluid levels. Further specialist checks may be needed for cylinder-head, gasket, turbo or cooler damage before returning to normal load.

OFFSHORE READINESS

Buyer questions and readiness checklist

An offshore-ready cooling system has demonstrated stable temperature under load, known flow paths, current maintenance and a crew able to distinguish a blocked intake from coolant loss, circulation failure or exhaust restriction.

Area	Questions for purchase or survey
Architecture	Can the closed-circuit and raw-water paths, cooler order, heater branches and exhaust-injection route be traced accurately?
Condition	Are seacocks, strainers, pumps, hoses, coolers, tanks, caps, belts and exhaust components accessible and credible?
Coolant history	Is the coolant type, concentration, age, top-up history and any contamination or pressure testing documented?
Raw-water history	Are impeller, anode, cooler-cleaning, mixing-elbow and missing-vane records available?
Loaded performance	Does the engine hold stable temperature with normal exhaust-water flow at representative propulsion load?
Overheat history	Are previous events explained, repaired and followed by evidence that secondary damage was excluded?
Degraded operation	What remains after one intake, pump, belt, sensor, heater branch or shared cooler fails?

Quick readiness check

	Readiness statement
	I can trace the closed-circuit coolant and raw-water routes from intake to exhaust.
	Normal cold level, warm-up, loaded temperature and exhaust-water flow are known.
	There are no unresolved leaks, repeated top-ups, air locks, restrictions or temperature trends.
	Coolant specification, concentration, age and refill/bleeding procedure are documented.
	Impeller, strainer, coolers, anodes, thermostat, hoses and exhaust injection are current.
	Missing impeller fragments and causes of previous overheating have been accounted for.
	Spares, tools and access support realistic owner-level recovery.
	More than one person knows the immediate response to raw-water loss and coolant loss.

KEY TAKEAWAY

A dependable engine cooling system combines correct coolant and pressure, unrestricted raw-water flow, clean heat-transfer surfaces, reliable pumps and thermostats, sound exhaust injection and early recognition of changing temperature or flow.

Guidance to consult

Use the installed engine, pump, heat-exchanger and exhaust manufacturers' current operating and service instructions, together with applicable flag-state, coding, class, insurance, environmental and yard requirements.

Understanding Yacht Systems

Practical guides for owners, buyers
and offshore cruising crews.

AMTG-014

Understanding Engine Cooling Systems

RELATED GUIDES

AMTG-013 Understanding Marine Diesel Engines
AMTG-015 Understanding Exhaust Systems
AMTG-018 Understanding Engine-Room Ventilation
AMTG-019 Understanding Lubrication Systems
AMTG-030 Understanding Seacocks and Through-Hull Fittings
AMTG-026 Understanding Monitoring and Alarm Systems

ABOUT ABSOLUTE MARINE

Independent technical advice for explorer yacht owners,
buyers and offshore cruising yacht owners.

Survey Report Reviews | Offshore Readiness Reviews
Reliability | Risk | Readiness

absolute-marine.co.uk

info@absolute-marine.co.uk